

∞

∞

Non-contact phase and phase sequence testing

- ∞ Phase Test at plug and junction boxes: red LED Probe + beep
- ∞ Rotating field testing in three-phase networks: green / red LED Probe for right / left rotation field
- ∞ Test phase balance
- ∞ Finding cable breaks in isolated and live wires
- ∞ LED flashing frequency of the probe tone frequency and increasing the voltage level
- ∞ ON / OFF switch with LED for standby phase and phase sequence test
- ∞ Voltage Range: 200V - 1000V AC
- ∞ Overvoltage category: CAT IV 600 V,