

## BENNING CM 11

<b>indicating range</b>	6,000
<b>basic accuracy</b>	1 %
<b>voltage AC</b>	0.01 V – 600 V
<b>voltage DC</b>	0.01 V – 600 V
<b>current DC</b>	0.1 mA - 10 A
<b>measuring ranges</b>	300.0 mA / 3.000 A / 10.00 A
<b>current AC</b>	0.1 mA – 20 A
<b>measuring ranges</b>	300.0 mA / 3.000 A / 20.00 A
<b>resistance</b>	0.1 $\Omega$ – 600 k $\Omega$
<b>continuity test</b>	yes
<b>memory</b>	HOLD, MIN / MAX, ZERO
<b>measuring method</b>	TRUE RMS
<b>max. clamp opening</b>	23 mm
<b>dimensions (l x w x h)</b>	206 x 76 x 33 mm
<b>measuring category</b>	CAT IV 300 V
<b>item no.</b>	044067